Root Crate

Compatible with Root Holds LROT, LROTE and LROTM

This product is not licensed, and is up for change at any time in the future.









Assembly Guide



Use an exacto knife to cut the bits connecting the parts to the frame




Always dry-fit the parts to together without any glue to make sure you are assembling the correct parts.



Remove the parts from the frame with a rotating motion along the axis formed by the bits vou just cut.



Use a drop of glue along the ioints and hold it in place until the glue has sufficiently dried.



knife to remove any of the remaining connection bits



Press the parts together or use a hobby hammer with slight force for assembly.

Use wood glue for assembly. Always dry fit the parts first to make sure the components are correct ones. If you encounter any issues, please contact us at info@laserox.net or our Facebook page at facebook.com/laseroxinserts.







