Endless Winter

Compatible with Endless Winter

This box organizer is compatible with Endless Winter This product is not licensed and is up for change at any time in the future.









Assembly Guide



Use the exacto

knife to remove

connection bits.

any of the

remaining



Use an exacto knife to cut the bits connecting the parts to the frame.



Most joints are press-fit, but some joints might require a drop of glue to ensure a strong bond.



with a rotating motion along the axis formed by the bits you just cut.

from the frame



Press the parts together or use a hobby hammer with slight force for assembly.





Use wood glue for assembly. If you encounter any issues, please contact us at info@laserox.net








Box Assembly














Watch our "How it fits" video and get your game organized! http://tiny.cc/lsrxlesw



Share your creation!




Holder





#laseroxinserts

5



- Some parts might look different than in the assembly instructions, with added decorations/engravings/embelishments.
 Color variations or branch marks are a natural part of the birch plywood.
- The burnt smell of wood is natural and will dissipate with time.
- Rarely the laser will not cut through the complete sheet, but this can be fixed with the help of a hobby knife. If that is not possible, please contact us for a replacement!

Hex Tile Holder A3 A3 B10

Required parts: **A3**x2, **B10**, **B5**x2

