

Glen More II: Highland Organizer

Glen More II: Highland Games


This product is licensed by Funtails™, and is up for change at any time in the future.




Assembly Guide



Watch our beginners guide videos on youtube. Just scan the QR code and get started!




Use an exacto knife to cut the bits connecting the parts to the frame.




Remove the parts from the frame with a rotating motion along the axis formed by the bits you just cut.

Use **wood glue** for assembly. Always dry fit the parts first to make sure the components are correct ones. If you encounter any issues, please contact us at info@laserox.net or our Facebook page at facebook.com/laseroxinserts.



Use the exacto knife to remove any of the remaining connection bits.



Always dry-fit the parts to together without any glue to make sure you are assembling the correct parts.




Use a drop of glue along the joints and press the parts together or use a hobby hammer with slight force for assembly.






14+ WARNING Choking hazard! Not for children under 14 years.

Part numbers






Some decorations may not be represented in the assembly manual only in the part numberings and on the actual product itself!

Chronicle Shelf






Required parts: **D2, D8, A3x2, A5x2, B1x2**

Card Holder






Required parts: **B2x2, D1x2, D4, D7x2,**

Chip Tray





Required parts: **C3, B4x2, D3, A4x2, C5x2,**

Coin Tray





Required parts: **C1, C8x2, B3x2, D6, C2x2, C7x2**

Large Tiles



Required parts: **A1, A2x2, C6x2,**

Small Tiles



Required parts: **C4, D5x2, B5x2**

Assembly

