MagneBitsBox short

Compatible with sleeved and unsleeved card crate.







Assembly Guide



Use an exacto knife to cut the bits connecting the parts to the frame.



Remove the parts from the frame with a rotating motion along the axis formed by the bits you just cut.



Always dry-fit the parts to together without any glue to make sure you are assembling the correct parts.

Compatible with sleeved and unsleeved card crate.



Use a drop of glue along the joints and hold it in place until the glue has sufficiently dried.



Use the exacto knife to remove any of the remaining connection bits.




Press the parts together or use a hobby hammer with slight force for assembly.



Use **wood glue** for assembly. Always dry fit the parts first to make sure the components are correct ones. If you encounter any issues, please contact us at **info@laserox.net** or our Facebook page at **facebook.com/laseroxinserts**.

MagneBitsBox short



Required parts: **A1**, **B1**x2, **C1**, **D1**, **E1**, **F1**x7 (optional), **G1**

!: Before assembly please make sure the pieces with magnets (E1,G1) have the correct orientation, so that the lid is attaching correctly.

