


# Mombasa Organizer

LMOB


Compatible with: Deutscher Spielepreis 2016 Goodie Box (2016)  
Mombasa: Cooked Books Mini Expansion (2016)  
Mombasa: E1/E2 Company Track (2015)  
Mombasa: Meeple BR Promo Card (2015)




## Assembly Guide



Use an exacto knife to cut the bits connecting the parts to the frame.




Remove the parts from the frame with a rotating motion along the axis formed by the bits you just cut.



Use the exacto knife to remove any of the remaining connection bits.


Use **wood glue** for assembly. Always dry fit the parts first to make sure the components are correct ones. If you encounter any issues, please contact us at [info@laserox.net](mailto:info@laserox.net) or our Facebook page at [facebook.com/laseroxinserts](https://www.facebook.com/laseroxinserts).



Always dry-fit the parts to together without any glue to make sure you are assembling the correct parts.



Use a drop of glue along the joints and hold it in place until the glue has sufficiently dried.



Press the parts together or use a hobby hammer with slight force for assembly.




5 999567 861429




**WARNING** Choking hazard!  
Not for children under 3 years.







Required parts: **D1, D2, D3, D6x2, D7, D8,**




Required parts: **A1, A2, A3, A6x2, A7, A8,**










Required parts: **A4x3, A5x3, C2, D4, D5,**




Required parts: **B4, C1x3, G1x2, G2, G3, G4, J1,**



Required parts: **B1, B2, B3, C3, C4, H1,**




**x3**







1



2




3



x2


Required parts: **E1**x2, **E2**x2, **E3**, **E4**, **F1**x2,



Company Tracks

Scoreboard

Gameboard



# LASEROX



Laserox Design Ltd.  
H-2092 Budakeszi  
Tiefenweg way 39

