Resistance Chest

Compatible with The Resistance®

This box organizer is compatible with The Resistance® This product is not licensed, and is up for change at any time in the future.

ASEROX

Assembly Guide



Use an exacto knife to cut the bits connecting the parts to the frame.



Remove the parts from the frame with a rotating motion along the axis formed by the bits you just cut.



Use the exacto knife to remove any of the remaining connection bits.



Press the parts together or use a hobby hammer with slight force for assembly.

Use wood glue for assembly. Always dry fit the parts first to make sure the components are correct ones. If you encounter any issues, please contact us at info@laserox.net or our Facebook page at facebook.com/laseroxinserts.








Always dry-fit the parts to together without any glue to make sure you are assembling the correct parts.





Use a drop of glue along the joints and hold it in place until the glue has sufficiently dried.







Resistance Chest









4










6 outer box top

3



7 Place the inner box into the outer box





ASEROX

laserox.net

Munchkin Chest















